



REQUIREMENTS FOR A VALID LED LIGHT WARRANTY

For your LED light warranty to be valid, you must ensure that you follow winterization procedure A. If you have an in-ground pool, you must also follow in-ground pool niche maintenance procedure B.

PROCEDURE A: LIGHT WINTERIZATION

- 1 **Open the round cover** on the sidewalk *For in-ground pool only*;
- 2 **Loosen the 3 butterfly screws** around the light (**DO NOT REMOVE THEM**);
- 3 **Hold the light** and **turn it** a quarter of a turn;
- 4 **Unhook the light** from the ring and **pull it out** onto the sidewalk;
- 5 Follow the wire to the "**Quick-Plug**" and **unscrew the black bolt**;
- 6 **Separate the wires** (male and female);
- 7 The **female wire must remain in place** in the junction box and it is recommended to **use grease** (e.g. Vaseline) **to avoid corrosion**;
- 8 **Store the light** in a dry, warm place if possible.

PROCEDURE B: NICHE MAINTENANCE

For in-ground pool only

Although the LED light is waterproof, it is not designed to soak in water. If it does and water seeps inside, the warranty will become void and you could lose LEDs until you run out of lights.

To ensure that there is no water accumulation in the niche, be sure to clean the bottom of the housing, where there are holes that allow water to drain out. If these holes become clogged with sand, dirt or rocks, water could reach the light and damage it, voiding the warranty.

REQUIRED TOOL:

Wet/Dry Vacuum Cleaner (like a 4HP or 6 HP Shop-Vac)



WARRANTY

IN-GROUND POOL

- LED Light: **3 years** from the installation date by a Lumi-O technician
- Remote control, transformer and installation: **1 year**

ABOVE GROUND POOL

- LED Light: **2 years** from the installation date by a Lumi-O technician
- Remote control, transformer and installation: **1 year**

You have questions?
Please contact us by phone or email

1-800-363-2396 / callcenter@lumi-o.com

