



WHAT TO DO WITH YOUR POOL LIGHTS WHEN YOU CLOSE YOUR POOL FOR THE WINTER?

In order to keep your pool lights in good condition, we suggest that you follow these procedures when closing your pool for the winter.

These procedures apply only to the conventional lighting system.



WINTERIZING THE LIGHTS

- 1 Open the round cover** on the sidewalk *For in-ground pool only*;
- 2 Loosen the butterfly screw** under the light (**DO NOT REMOVE IT**);
- 3 Hold the light** and **turn it** a quarter of a turn to unhook it from the ring;
- 4 Remove the bulb** and **store it** in a dry, warm place if possible;
- 5** To prevent the formation of verdigris and rust, **apply petroleum jelly** (Vaseline or white grease) in the socket;
- 6 Place the lamp (shell) in a plastic bag** with the opening facing down in the bottom of the housing, or on the ground for an above ground pool if the wire is long enough. Otherwise, you must hang it up on the ring.

NICHE MAINTENANCE

FOR IN-GROUND POOL ONLY

To ensure that there is no water accumulation in the niche, be sure to clean the bottom of the housing, where there are holes to allow water to drain out. If these holes are clogged with sand, dirt or rocks, water could reach the light and damage it.



REQUIRED TOOL:

Wet/Dry Vacuum Cleaner (like a 4HP or 6 HP Shop-Vac)





FREQUENTLY ASKED QUESTIONS

None of the lights are working:

- Test an electrical device in the electrical outlet to make sure it is working;
- If you have a breaker, press the "reset" button (under the spring cover) and test an electrical device;
- Check the light bulbs.

Only one light does not work:

- Try the light bulb in a household lamp;
- If you have a breaker, unplug it. Unscrew the bulb and using a screwdriver, lift the metal tab at the bottom of the socket so that contact occurs;
- Check the voltage in each socket as it may be too low (the wire in the ground may be damaged);
- If rust or lime has formed in the socket, clean with "bulldog" style steel wool.

Remote control:

- If you have a remote control, it may be defective. Unplug it and try turning on the light directly.

WARRANTY

IN-GROUND POOL

- Light: **3 years**
- Breaker and installation: **1 year**

ABOVE GROUND POOL

- Light: **2 years**
- Breaker and installation: **1 year**

You have questions? Please contact us by phone or email.

1-800-363-2396 / callcenter@lumi-o.com